

**Embedded
Code Generation**
DEMO MODEL

Multiphase Buck Converter

Use the high resolution timer (HRTIM) to generate advanced PWM signals for a three-phase interleaved buck converter with phase-shedding.

Last updated in STM32 TSP 1.3

www.plexim.com

- ▶ Request a PLECS and PLECS Coder trial license
- ▶ Get the latest STM32 and RT Box Target Support Package
- ▶ Check the PLECS, RT Box and STM32 TSP documentation

1 Overview

This STM32 demo model features an interleaved buck converter as described in the application note AN4539 from STMicroelectronics [1].

The power circuit consists of a three-phase interleaved buck converter feeding a common load. Changing dynamically the number of interleaved phases, also known as phase shedding, will increase the converter efficiency at light load conditions. In addition, a multiphase buck topology has the advantage of reduced current ripple on the output capacitor.

The following sections provide a brief description of the model and instructions on how to simulate the model, and deploy the control code to the STM32 target.

Note This model contains model initialization commands that are accessible from:

PLECS Standalone: The menu **Simulation + Simulation Parameters... + Initializations**

PLECS Blockset: Right click in the **Simulink model window + Model Properties + Callbacks + InitFcn***

2 Requirements

In order to run this model you will need:

- PLECS Blockset or Standalone 4.6.7 or newer
- PLECS Coder
- STM32 Target Support Package 1.3.1 or newer
- RT Box Target Support Package
- 1 PLECS RT Box
- 1 RT Box NUCLEO Interface board
- 1 NUCLEO-G474RE STM32 Nucleo board

The Plant model can be executed on all versions of the RT Box. The controller can be executed on a NUCLEO-G474RE Nucleo board.

3 Model

The top-level schematic contains the power circuit and the controller, as shown in Fig. 1. Both subsystems are enabled for code generation from the **Subsystem + Execution settings...** context menu. This step is necessary to generate the model code for a subsystem via the PLECS Coder.





Figure 1: Top level schematic of the demo model


Figure 3: Controller subsystem

relative phase-shift Θ_{ph} changes in function of the number of active phases and is given as:

$$\Theta_{ph} = \frac{360^\circ}{N_{ph}} \quad (1)$$

The master timer is running in continuous mode and resets the synchronized timing units periodically. The three reset signals for the timing units are generated by three internal compare registers of the master timer. The value of each compare register is calculated to generate the requested phase-shift. However, the duty cycle is handled by each of the three timing units locally.

This is also illustrated in Fig. 4. In addition, the sampling points are indicated by colored flashes. For a sawtooth carrier, the sampling point instant has to be adjusted every time the duty cycle changes. For phase three, the resulting inductor current is sketched. As illustrated, the sampling point represents the average current.

The number of active phases are computed based on the total load current. The total load current is estimated as the sum of the individual currents of the active phases. Due to small loop delays, the sampling point no longer lies in the middle of the on-time of the PWM signal. This leads to a wrong average current values. The estimated sampling error is compensated by software. The following equations describe the compensation:

$$i_x^* = \begin{cases} i_x + \frac{V_{in} - V_{out}}{L} T_{delay} & \text{for } T_{delay} \leq \frac{T_{on}}{2} \\ i_x + \frac{V_{in} - V_{out}}{L} \frac{T_{on}}{2} - \frac{V_{out}}{L} (T_{delay} - \frac{T_{on}}{2}) & \text{for } T_{delay} > \frac{T_{on}}{2} \end{cases} \quad (2)$$

i_x^* describes the compensated phase current and i_x is representing the sampled phase current. V_{in} and V_{out} are the input and output voltage of the converter, L describes the nominal phase inductor value. T_{delay} is the measured loop delay and T_{on} is the duration of the PWM on-time in seconds.

The number of active phases are adjusted dynamically, depending on the load current. Every time the number of active phases changes, the phase-shift of the remaining phases needs to be rearranged.

The converter is controlled by nested voltage and current control loops. One single outer voltage loop ensures tight regulation of the load voltage. The voltage controller provides the current setpoint of the




Figure 4: Interleaved PWM generation for three active phases. The colored flashes are indicating the sampling points of the three phases.

three inner current control loops. Each interleaved phase has its own current controller. Individual current control loops will ensure equal current sharing among the active phases. The current control loops provide the compare value between 0 and 1 to the HRTIM timing unit.

An estimate of the used processor resources can be obtained from the Base Task Load block from the STM32 component library. The value represents the duration of the base task relative to the configured Discretization step size in the Coder options, in percent.

The blinking LED (LD2) indicates a running firmware on the MCU.

4 Simulation

4.1 Offline simulation

Run the model as provided from **Simulation + Start**, to observe the results from the offline simulation. Fig. 5 shows the results from the Scope in the “Plant” subsystem.

At 0.001 s, the USER button is pressed and the controller enabled. First, only a relative light load condition is simulated. Therefore, only one phase is active. At time 0.1 s the load is increased. This activates the second buck converter. Finally, at 0.2 s the load is increased once again. At this operating point all three converters work in parallel and participate equally to the total load current.




Figure 5: Offline simulation result of increasing load steps

4.2 Configuring the STM32 Target

In addition to running a simulation of this demo model in offline mode on a computer, the “Controller” subsystem can be directly converted into target specific code for the STM32G474RE NUCLEO board.

Follow the instructions below to upload the “Controller” subsystem to a STM32 MCU.

- Connect the MCU to the host computer through a USB cable.
- From the **System** tab of the **Coder + Coder options...** window, select “Controller”.
- Next, from the **Target** tab, select STM32G4x from the dropdown menu. Then under the **General** sub-tab, select the chip G474RE.
- To deploy the MCU target directly from PLECS, uncheck the **Generate code only** parameter, choose the desired **Programming interface** from the dropdown menu. The default programming interface is OpenOCD.
- Then click **Build**.

If programmed correctly, the green LED “LD2” on the NUCLEO board should blink.

Note Verify the jumper configuration on the NUCLEO board: JP5 not populated, JP8 in position [2–3], JP6 closed.

4.3 Configuring the PLECS RT Box

Prior to controlling a real power stage with the programmed MCU, it is highly recommended to first verify the behavior of the controller using a PLECS RT Box and perform a HIL test. A typical hardware configuration is shown in Fig. 6, where the NUCLEO board (the light blue board) is connected to the RT Box via an RT Box NUCLEO Interface board (the green board).

Follow the instructions below to run a real-time model on the RT Box. The “Plant” subsystem is executable on all RT Box platforms.

- From the **System** tab of the **Coder + Coder options...** window, select “Plant”. Click the **Target** tab and select a target device. Then click **Build** to deploy the model to the target RT Box.
- Once the model is uploaded, from the **External Mode** tab of the **Coder options...** window, **Connect** to the RT Box and **Activate autotriggering** to observe the test results in real time.

If programmed correctly, the LED corresponding to “DO-31” of the RT Box NUCLEO Interface board should blink.




Figure 6: Hardware setup for the HIL verification

4.4 Executing a Closed-Loop HIL Test

Enable the MCU by pushing the blue “User” push-button on the NUCLEO board. This initiates the PWM signal generation. Observe the real-time waveforms in the Scope of the “Plant” subsystem.

Toggling the switches “DI-28” and “DI-29” on the RT Box LaunchPad Interface board from low to high will increase the load of the converter.

To observe any intermediate values calculated on the MCU, follow the instructions below to connect to the external mode of the STM32 MCU.

- First, **Disconnect** the “Plant” subsystem from the **External Mode** of the PLECS RT Box, if connected.
- From the **System** menu on the left hand side of the **Coder + Coder options...** window, select “Controller”.
- Next, from the **External Mode** tab, select the appropriate **Target device** and click **Connect**.
- Then, **Activate autotriggering** to observe the test results in the “Controller” subsystem Scope.

Then, connect to the external mode of the RT Box again following the instructions provided in Section 4.3.

To stop the operation of the multiphase converter, push the blue “User” push-button on the NUCLEO board once again. This will stop the PWM signal generation and the controller will enter an idle state, waiting for the next push on the “User” push-button.

5 Conclusion

This models demonstrated how to use the HRTIM Master and HRTIM timing unit blocks to generate PWM signals for a multiphase buck converter with load shedding. The model can be run in both of-line mode, as well as in real time.

References

- [1] AN4539, HRTIM cookbook, 2020, Chapter: 7
- [2] J. Allmeling, and N. Felderer, "Sub cycle average models with integrated diodes for real-time simulation of power converters," IEEE Southern Power Electronics Conference (SPEC), 2017.

Revision History:

STM32 TSP 1.3 First release

How to Contact Plexim:

☎	+41 44 533 51 00	Phone
	+41 44 533 51 01	Fax
✉	Plexim GmbH Technoparkstrasse 1 8005 Zurich Switzerland	Mail
@	info@plexim.com	Email
	http://www.plexim.com	Web

Embedded Code Generation Demo Model

© 2002–2022 by Plexim GmbH

The software PLECS described in this document is furnished under a license agreement. The software may be used or copied only under the terms of the license agreement. No part of this manual may be photocopied or reproduced in any form without prior written consent from Plexim GmbH.

PLECS is a registered trademark of Plexim GmbH. MATLAB, Simulink and Simulink Coder are registered trademarks of The MathWorks, Inc. Other product or brand names are trademarks or registered trademarks of their respective holders.